



## TORQUE CONVERTER GP

PART NUMBER	DESCRIPTION	MACHINE MODEL	ENGINE MODEL
1T-1815	CARRIER	769	3408
1T-1931	CARRIER	910F	3114
1T-1397	CARRIER	916-926	3204-3304
1T-0555	CARRIER	930-920	3304
1T-1508	CARRIER	936E	3304
1T-1887	CARRIER	936F	3304
1T-1852	CARRIER	938F-938G	3116-3126
1T-1522	CARRIER	950B	3304
1T-1946	CARRIER	950F	3116
115-2025	CARRIER	950G-950GII	3126-3126B
3T-2145	CARRIER	966E.966D	3306
7T-8518	CARRIER	966F-972G-966G	3306
171-6348	CARRIER	972H-966H	C11-C13
6P-6556	CARRIER	980F-980G	3406
1T-1339	CARRIER	980F-980G-980H	3406-3406E-C15
1T-1534	CARRIER	980G II-980H	3406E.C15
7T-4081	CARRIER	988B	3408
6Y-4573	CARRIER	988F	3408-3408E
6P-9163	CARRIER	D10N.D9L-D10R	3412-3412E
7G-6059	CARRIER	D10N.D9L-D10R-D9N-D8L	3412-3406
7G-6059	CARRIER	D10R	3412E
8P-5229	CARRIER	D8L-D9N-D9R-D10R	3406-3408-3412E
1T-0064	CARRIER	D8N	3406
1T-1784	CARRIER	D8N	3406
1T-1847	CARRIER	D8R	3406
1T-2050	CARRIER	D8R	3406
1T-0782	TURBINE	769	3408
1T-0842	TURBINE	920	3304
1T-1801	TURBINE	910F	3114
1T-0079	TURBINE	916-926	3304-3204

Menderes mah.Alparslan cad. No 44/2  
Sincan Ankara/Turkey

[Tel:+90 3123947409](tel:+903123947409)

[Mail:info@feridemakina.com](mailto:info@feridemakina.com)



## TORQUE CONVERTER GP

PART NUMBER	DESCRIPTION	MACHINE MODEL	ENGINE MODEL
1T-0020	TURBINE	930-936E-936F	3304
1T-1805	TURBINE	938F-938G	3116-3126
1T-1480	TURBINE	950B	3304
1T-1053	TURBINE	950F	3116
6Y-3149	TURBINE	950G.950GII	3126-3126B
8P-0953	TURBINE	966E.966D	3306
6Y-1089	TURBINE	966F-972G-966G	3306
2P-5680	TURBINE	980F-980G-980H-988B	3406-3408-C15
6Y-6537	TURBINE	988F	3408-3408E
8P-9265	TURBINE	D10N.D9L-D10R-D9N-D8L	3406-3412
1T-0052	TURBINE	D8N	3406
1T-1993	TURBINE	D8R	3406
1T-0538	WHEEL	926	3204
1T-0292	WHEEL	930-936E-920	3304
1T-0407	WHEEL	936F	3304
1T-1329	ADAPTER	950F	3116
6Y-1093	ADAPTER	950G.950GII-966F	3116-3126-3306
9W-8384	HUB	966E.966D	3306
8E-6539	HUB	966F-972G-966G	3306
8P-0769	HUB	980B-980G	3406
8P-0769	HUB	980F	3406
9W-6434	HUB	980F-980G-980H	3406-C15
8P-6817	HUB	D10N-D9L-966D	3412-3306
7G-5671	HUB	D8L-D9N-D9R-D10R	3406-3408-3412E
1T-1770	HUB	D8N	3406
1T-1359	HUBE	769	3408
8P-0768	HUBE	980F-988F	3406-3408E
3T-5416	HUBE	988F	3408-3408E
1T-0781	IMPLLER	769	3408
1T-1447	IMPLLER	916	3204
1T-0841	IMPLLER	920	3304
1T-1446	IMPLLER	926	3204
1T-0851	IMPLLER	930	3304
1T-1797	IMPLLER	910F	3114
1T-1647	IMPLLER	936E	3304
1T-1691	IMPLLER	936F	3304
1T-1727	IMPLLER	938F-938G	3116-3126

Menderes mah.Alparslan cad. No 44/2  
Sincan Ankara/Turkey

[Tel:+90 3123947409](tel:+903123947409)

[Mail:info@feridemakina.com](mailto:info@feridemakina.com)



**Feride**

**TORQUE CONVERTER GP**

PART NUMBER	DESCRIPTION	MACHINE MODEL	ENGINE MODEL
1T-1438	IMPELLER	950B	3304
1T-1953	IMPELLER	950F	3116
6Y-1085	IMPELLER	950G.950GII	3126-3126B
8P-0960	IMPELLER	966E.966D	3306
6Y-1084	IMPELLER	966F	3306
8E-9972	IMPELLER	972.966G	3306
8E-2417	IMPELLER	980F	3406
9W-5278	IMPELLER	980G-980G II-980H	3406-C15
3T-5102	IMPELLER	988B	3408
3T-5103	IMPELLER	988B	3408
8E-6742	IMPELLER	988F	3408E
9W-1566	IMPELLER	988F	3408E
9P-6477	IMPELLER	D10N.D9L	3412
9P-6476	IMPELLER	D8L-D9N-D9R	3406-3408
1T-0699	IMPELLER	D8N-D8R	3406
1T-1942	SHAFT	950F	3116
115-2023	SHAFT	950G-950GII	3126-3126B
9G-2413	SHAFT	966E.966D	3306
6Y-3148	SHAFT	966F-972G-966G	3306
148-0885	STATOR	769	3408
1T-0080	STATOR	916-910F	3114-3204
1T-1729	STATOR	938F-938G	3116-3126
1T-1331	STATOR	950B-950F	3304-3116
6Y-3151	STATOR	950G.950GII	3126-3126B
9P-9517	STATOR	966E.966D	3306
6Y-1090	STATOR	966F-972G-966G	3306
9W-4702	STATOR	980F-980G-980H	3406-C15
2P-5702	STATOR	988B	3408
8E-3726	STATOR	988F	3408E
8P-9266	STATOR	D10N.D9L-D10R-D9N-D8L	3406-3412
1T-0937	STATOR	D8N	3406
1T-2052	STATOR	D8R	3406

**Menderes mah.Alparslan cad. No 44/2  
Sincan Ankara/Turkey**

**[Tel:+90 3123947409](tel:+903123947409)  
[Mail:info@feridemakina.com](mailto:info@feridemakina.com)**